

Kelin Polyurea Tile Grout shine sabon samfurin da ke tattare. Saboda polyurea s kyakkyawan abin da-juriya, lalata juriya, juriya da rawaya, ana amfani dashi a masana\`antar soji. Bugu da kari, yana haɓaka da sauri, gini da tsabta a rana ɗaya, adana lokaci da farashin kuɗi. Mafi mahimmanci, ana iya gina shi a cikin rigar gangara, wanda ya magance matsalar da ba zata iya sarrafawa ba saboda yanayin yanayi da sauran dalilai da sauran dalilai da sauran dalilai. Australia hadin gwiwar cigaba da kayayyakin ci gaba don yin kyakkyawan aiki, kuma ta hanyar ilimin kimiyyar kasar Sin kan Kimiyyar Kimiyyar Kimiyya ta Kimiyya, don sanya ingantattun kayayyaki.

Ana iya amfani da samfurin mafi kyau a cikin gidajen tayal, dutse, gilashin mosaic a bango ko gari a cikin gidan wanka, dafa abinci da sauransu. China KELIN [Cika Manufar Grower](#) ya kasance a cikin wannan filin shekaru 14. Muna da kungiyar R & D da masana\`antu. Bauseariyar kariya na kayan kimiyya shine mai sauƙin gini, samun taimako mai amfani mai sauƙi. Don haka Kelin [Tile Ruut](#) zai samar muku da ingantattun kayayyaki. Barka da saduwa [Masana\`antu na Epoxy na China](#) lokacin da kuke bukata.



Irin launuka na launuka don zaɓinku. Hakanan samar da launuka na musamman.

- Gray 1#
- Gray 2#
- Gray 3#
- Gray 4#
- Gray 5#
- Gray 6#
- Gray 7#
- Gray 8#
- Gray 9#
- Cement Gray
- Dull Gray
- Silver Gray
- Metal Gray
- Luxury Silver
- Glacier White
- Calaeatta
- Pearl Gold
- Slate Gray
- Terra Brown
- Greyish Green
- Yellow Gray
- Soft Khaki
- Yellowish Brown
- Olive Brown
- Brownness
- Dark Brown
- Reddish Brown
- Rock Bslack



Samar da cikakkiyar hanyar daki



Brief aikin gini



01 Clean the tiles and keep it dry



02 Polish with tile wax except the glazed tile



03 Open & Watch, both sides can extruded meanwhile



04 Screw on the nozzle, put on the grout gun



05 Inclined cut the top of the nozzle in 45°



06 Squeeze out 60-80cm long grout in the forepart



07 Evenly squeeze out the tile agent along the gap



08 Press the grout with professional glue-press tools



09 Don't touch in 4-5 hours and remove excess grout then.



10 Keep the tiles dry in 24 hours

Kayan aiki mai dorewa



Two Component Caulking Gun



02 Cutter Knife



03 Pointing trowel



04 Brush



05 Forming Stick



06 Perching Knife



07 Masking Tape



08 Stainless Steel Ball



09 Cleaning Awl

Amfani da Kamfanin



Fastocin masana\anta



Creaming Machine Line



Testing Machine



Batching Production Line



Cooling Filling



Filling Machine Line



Film-coated Machine



Real Material Stock



Stock

Ba da takardar shaida

