

Abubuwan haɗin kelin epoxy mai ɗorawa sabon samfuri ne wanda aka haɓaka bayan launuka masu launi na ruwa mai ruwa, ba wai kawai yana riƙe da yanayin launuka mai launi mai ruwa mai ɗauke da ruwa ba, yana haɓaka aikin samfuri, amma kuma yana sa ginin ya zama mai sauƙi da sauƙi. Taushi mai laushi, yana nuna ƙananan maɓallin keɓaɓɓen kayan ado na ado. Iri-iri launuka, sanya adonku ya zama mai walƙiya. Eco-friendly epoxy guduro subbase hanya bari samfur naka ya zama mai hana ruwa, lalacewa mai jurewa, tabbataccen sifa da hujjar danshi. Sand sandar ƙasa da aka zana a babban zafin jiki yana sa launi ya zama na halitta da kyau kuma ba ya shuɗewa. Har ila yau, yana da haske kamar ainin bayan cluing ba tare da rawaya ko ado ba. Bugu da kari, yanayin haɗin gwiwa yana kama da dacewa da tayal yumbu, kamar yanayin kanta. Za'a iya amfani da samfuri mafi kyau a cikin haɗin tayal na yumbu, dutse, gilashi, tayal mosaic akan bango ko gari a cikin bandaki, kicin, ɗakin kwana da sauransu. Ostiraliya haɗin haɗin gwiwa da samfuran ci gaba don haɓaka aiki mafi kyau, kuma ta hanyar Kwalejin Kwalejin Kimiyyar Kimiyya ta China dabarun kula da ingancin ingancin, don samar da samfuran ingantacce. Kyakkyawan zaɓin samfur Kelin [China sau biyu kayan aiki epoxy gap filler ma'aikata](#).



**Iri launuka don zaɓin ku. Hakanan samar da launuka na al'ada.**

Gray 1#

Gray 2#

Gray 3#

Gray 4#

Gray 5#

Gray 6#

Gray 7#

Gray 8#

Gray 9#

Cement Gray

Dull Gray

Silver Gray

Metal Gray

Luxury Silver

Glacier White

Calaeatta

Pearl Gold

Slate Gray

Terra Brown

Greyish Green

Yellow Gray

Soft Khaki

Yellowish Brown

Olive Brown

Brownness

Dark Brown

Reddish Brown

Rock Bslack



Bayar da Maganin Tazarar Dukan Room



**Takaitaccen Tsarin Ginawa**





01  
Clean the tiles and keep it dry



02  
Polish with tile wax except the glazed tile



03  
Open & Watch, both sides can extruded meanwhile



04  
Screw on the nozzle, put on the grout gun



05  
Inclined cut the top of the nozzle in 45°



06  
Squeeze out 60-80cm long grout in the forepart



07  
Evenly squeeze out the tile agent along the gap



08  
Press the grout with professional glue-press tools



09  
Don't touch in 4-5 hours and remove excess grout then.



10  
Keep the tiles dry in 24 hours

### Kwarriyar Matsa Hafin gwiwa



Two Component Caulking Gun



Cutter Knife



Pointing trowel



Brush



Forming Stick



Perching Knife



Masking Tape



Stainless Steel Ball



Cleaning Awl

### Amfanin Kamfanin



## Bayanin Masana'antu



Layin Na'urar Yin Kuka



Injin gwaji



Layi Production Line



Sanyin Filing



Ciko Layin Na'ura



Injin da aka lullube da fim



Hakikanin Haja



Haja

## Takardar shaida

