

Abubuwan haɗin kelin epoxy mai ɗorawa sabon samfuri ne wanda aka haɓaka bayan launuka masu launi na ruwa mai ruwa, ba wai kawai yana riƙe da yanayin launuka mai launi mai ruwa mai ɗauke da ruwa ba, yana haɓaka aikin samfurin, amma kuma yana sa ginin ya zama mai sauƙi da sauƙi. Taushi mai laushi, yana nuna ƙananan maɓallin keɓaɓɓen kayan ado na ado. Iri-iri launuka, sanya adonku ya zama mai walkiya. Eco-friendly epoxy guduro subbase hanya bari samfur naka ya zama mai hana ruwa, lalacewa mai jurewa, tabbataccen sifa da hujjar danshi. Sand sandar ƙasa da aka zana a babban zafin jiki yana sa launi ya zama na halitta da kyau kuma ba ya shuɗewa. Har ila yau, yana da haske kamar ainin bayan cluing ba tare da rawaya ko ado ba. Bugu da kari, yanayin haɗin gwiwa yana kama da dacewa da tayal yumbu, kamar yanayin kanta. Za'a iya amfani da samfurin mafi kyau a cikin haɗin tayal na yumbu, dutse, gilashi, tayal mosaic akan bango ko gari a cikin bandaki, kicin, ɗakin kwana da sauransu. Ostiraliya haɗin haɗin gwiwa da samfuran ci gaba don haɓaka aiki mafi kyau, kuma ta hanyar Kwalejin Kwalejin Kimiyya ta China dabarun kula da ingancin ingancin, don sa samfuran su zama masu inganci. Kelin mai sassaukaƙken kayan masarufi ya sanya gidanka na musamman.



Iri launuka don zaɓin ku. Hakanan samar da launuka na al'ada.

Gray 1#

Gray 2#

Gray 3#

Gray 4#

Gray 5#

Gray 6#

Gray 7#

Gray 8#

Gray 9#

Cement Gray

Dull Gray

Silver Gray

Metal Gray

Luxury Silver

Glacier White

Calaeatta

Pearl Gold

Slate Gray

Terra Brown

Greyish Green

Yellow Gray

Soft Khaki

Yellowish Brown

Olive Brown

Brownness

Dark Brown

Reddish Brown

Rock Bslack



Bayar da Maganin Tazarar Dukan Room



Takaitaccen Tsarin Ginawa



01
Clean the tiles and keep it dry



02
Polish with tile wax except the glazed tile



03
Open & Watch, both sides can extruded meanwhile



04
Screw on the nozzle, put on the grout gun



05
Inclined cut the top of the nozzle in 45°



06
Squeeze out 60-80cm long grout in the forepart



07
Evenly squeeze out the tile agent along the gap



08
Press the grout with professional glue-press tools



09
Don't touch in 4-5 hours and remove excess grout then.



10
Keep the tiles dry in 24 hours

Kwarriyar Matsa Hafin gwiwa



Two Component Caulking Gun



02
Cutter Knife



03
Pointing trowel



04
Brush



05
Forming Stick



06
Perching Knife



07
Masking Tape



08
Stainless Steel Ball



09
Cleaning Awl

Amfanin Kamfanin



Bayanin Masana'antu



Layin Na'urar Yin Kuka



Injin gwaji



Layi Production Line



Sanyin Filing



Ciko Layin Na'ura



Injin da aka lullube da fim



Hakikanin Haja



Haja

Takardar shaida

