

Kelin Polyurea Tile Grout shine sabon samfurin da ke tattare da shi. Saboda polyurea s kyakkyawan wurin da-juriya, lalata juriya, juriya da rawaya, ana amfani dashi a masana'antar soji. Bugu da kari, yana haɓaka da sauri, gini da kuma tsabta a rana ɗaya, adana lokaci da farashin kuɗi. Mafi mahimmanci, ana iya gina shi a cikin rigar gangara, wanda ya magance matsalar da ba zata iya ginawa ba saboda yanayin yanayi da sauran dalilai da sauran dalilai da sauran dalilai da sauran dalilai. Australia hadin gwiwar cigaba da kayayyakin ci gaba don yin aikin ingantacciyar aiki, kuma ta hanyar kwarewar Kimiyya mai ingancin Kimiyya, don sanya ingantattun kayayyaki.

Samfurin [Mai sarrafa mai ruwa ta hanyar China](#) Za a iya amfani da mafi kyau a cikin gidajen tayal, dutse, gilashi, matashin Mosai'a a kan bango ko gari a gidan wanka, dafa abinci, ɗakin kwana da sauransu. China Kelin [Liquid Tile Grout wa'azan](#) ya kasance a cikin wannan filin shekaru 14. Muna da ƙungiyar R & D da masana'antu. Because amincin kayan kimiyya shine mai sauƙi, samun taimako mai amfani mai amfani. Don haka Kelin [Gray for Fale sna upler](#) zai samar muku da ingantattun kayayyaki. Barka da saduwa [China Inalant na Sealant masana'anta](#) lokacin da kuke bukata.



Irin launuka na launuka. Hakanan samar da launuka na musamman.

- Gray 1#
- Gray 2#
- Gray 3#
- Gray 4#
- Gray 5#
- Gray 6#
- Gray 7#
- Gray 8#
- Gray 9#
- Cement Gray
- Dull Gray
- Silver Gray
- Metal Gray
- Luxury Silver
- Glacier White
- Calaeatta
- Pearl Gold
- Slate Gray
- Terra Brown
- Greyish Green
- Yellow Gray
- Soft Khaki
- Yellowish Brown
- Olive Brown
- Brownness
- Dark Brown
- Reddish Brown
- Rock Bslack



Bayar da mafita na daki



Brief aikin gini



01 Clean the tiles and keep it dry



02 Polish with tile wax except the glazed tile



03 Open & Watch, both sides can extruded meanwhile



04 Screw on the nozzle, put on the grout gun



05 Inclined cut the top of the nozzle in 45°



06 Squeeze out 60-80cm long grout in the forepart



07 Evenly squeeze out the tile agent along the gap



08 Press the grout with professional glue-press tools



09 Don't touch in 4-5 hours and remove excess grout then.



10 Keep the tiles dry in 24 hours

Kayan aiki mai dorewa



Two Component Caulking Gun



02 Cutter Knife



03 Pointing trowel



04 Brush



05 Forming Stick



06 Pointing Knife



07 Masking Tape



08 Stainless Steel Ball



09 Cleaning Awl

Amfani da Kamfanin



Fastocin masana'anta



Creaming Machine Line



Testing Machine



Batching Production Line



Cooling Filling



Filling Machine Line



Film-coated Machine



Real Material Stock



Stock

Ba da takardar shaida

